


Please note:

- 1. Cold temperatures require up to 40 amp (below 0 Fahrenheit / -17 Celsius).
- you will need to check the specific manufactures' specifications.

2. This wiring diagram is specific to the most common breakaway kits. However, there maybe different breakaway kits, which use other wiring configuratuions and color codes. Therefore,

WIRING DIAGRAM



BLACK 25-40 AMP 12V SUPPLY - TOW VEHICLE BLUE OUTPUT IN CAB CONTROLLER