
WIRING DIAGRAM



Please note:

- 1. Cold temperatures require up to 40 amp (below 0 Fahrenheit / -17 Celsius).
- 2. This wiring diagram is specific to the most common breakaway kits. However, there maybe different breakaway kits, which use other wiring configuratuions and color codes. Therefore, you will need to check the specific manufactures' specifications.